

## **GLITTER FLUORESCENCE RAINBOW**







GRF-64





GRF-65

GRF-68



OEKO-TEX ® CONFIDENCE IN TEXTILES STANDARD 100 1110046 Centexbel United for harmful substances www.eko-tex.com/standard100

GRF-63



Mehmet Nesih Özmen Mah. Savur Sk. No: 22 Merter - Güngören / İstanbul / TURKEY Tel: +90 212 637 37 10 Faks: +90 212 637 37 80

# **GLITTER FLUORESCENCE RAINBOW**

#### DESCRIPTION

Glitter material for computer cutting applications

#### **SPECIFICATIONS**

**Size:** 50 cm x 50 m **N.W:** 11 kg / roll

## **TRANSFER CONDITIONS**

The following instructions are given as guideline only. **Temperature:** 150°C (302°F) 160°C (320°F) **Pressing time:** 10 ~ 15 seconds

## **HOW TO USE**

1) Cut an image on the glitter in reverse by a plotter machine.

- 2) Weed the exess glitter.
- 3) Place the image on a T-Shirt.
- 4) Press it on at medium pressure for 10 to 15 seconds.
- 5) Remove the polyester backing film while it is warm/cool.

## **SUITABLE FOR**

Cotton, mixtures of polyester / cotton and polyester / acrylic or for similar textile.

Not suitable for treated and dyed garments.

## NOTICE

All information given in this sheet is based on our experience. We recommend you to perform a test prior to standart production.



Cut the image in reverse



150°C (302°F) ~160°C (320°F)



Medium, even pressure

88:88

10 - 15 seconds for pressing



Peel WARM/COOL



Mehmet Nesih Özmen Mah. Savur Sk. No: 22 Merter - Güngören / İstanbul / TURKEY Tel: +90 212 637 37 10 Faks: +90 212 637 37 80 www.trutape.com.tr/en

